

## Fitting Instructions – Atlantic D Pull Handle (bolt through) 150mm x 19mm

# APH15019

Date Modified: 20/09/2022

Last modified by: Brock H

For best results when fixing a finger plate follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Note: Atlantic UK recommends fitting a D Pull Handle before fixing a push plate.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 D pull handle

X2 Bolts

- 1) First, mark out the desired position of the pull handle on the pull side of the door. Mark out your hole centers to match up with the threaded holes on the pull handle.
- 2) Then, drill out the counterbore for the head of the bolt using the appropriate bit.
- 3) Now, fully drill the hole all the way through the door using an appropriate drill bit allowing the bolt to pass through.
- 4) Next, place the bolts in the holes.
- 5) Finally, offer up the Pull handle to the bolts and secure in place.